

Multi-tank Option

If one motor is filling more than one overhead tank simultaneously, individual transmitters will be installed for each tank. The controller will start the motor if the water level in any tank goes below minimum level and keep running motor till all the tanks get 100% filled. The controller will display the water level of the tank which have least water. For this system it is compulsory that all tanks are fitted with Ball-Valve. This Add-on is available in all automatic models. It can work for maximum five overhead tanks.